


Esplso spazzola vapore stirante – Exploded view steam brush with ironing plate

Legenda – Parts List



Cod.	Descrizione	Description
3600.011	Vite	Screw
430704	Tasto micro	Microswitch button
431701	Raccordo vapore	Steam fitting
46000000	Manico	Handle
460100	Piastra	Sole plate
460507	Calotta	Cover
461010	Monotubo	Monotube
461102	Collegamento elettrico	Electric wire
461103	Collegamento elettrico	Electric wire
461700	Guaina isolante	Sheath
462001	Tubino silicone	Silicone hose
462201	Piastra stirante	Ironing sole plate
4650	Termostato	Thermostat
4652	Vite	Screw
4654	Termostato a riarmo	Thermostat with manual reset
4661	Vite	Screw
501400	Rondella isolamento	Insulation washer
5954	Vite	Screw
R228	Vite	Screw
R329	Fascetta fermacavo	Clamp
R3832	Microinterruttore	Microswitch
R3840	Rondella	Washer
R3846	Fascetta bifilare	Clamp
R4311	Passacavo	Fairlead
R4314	Corsoio	Slide key
R4320	Giunto vapore	Steam joint
R730	Vite	Screw